

Maximum pipe span chart

Maximum Pipe Span Chart: A Comprehensive Guide for Engineers and Contractors

Understanding the maximum pipe span chart is essential for architects, engineers, contractors, and plumbing professionals involved in designing and installing piping systems. Proper pipe span calculations ensure the structural integrity, safety, and longevity of the piping infrastructure. This article provides an in-depth overview of the maximum pipe span chart, its importance, factors influencing pipe spans, standard guidelines, and practical applications.

What is a Maximum Pipe Span Chart?

A maximum pipe span chart is a visual or tabular reference tool that indicates the maximum allowable distance between supports (such as hangers, brackets, or supports) for various pipe sizes, materials, and load conditions. It helps determine how far apart supports can be placed without risking excessive deflection, vibration, or failure.

Key Components of a Pipe Span Chart:

- Pipe diameter and size
- Pipe material (e.g., steel, PVC, copper)
- Pipe thickness or schedule
- Support spacing (span)
- Load conditions (full or partial)
- Temperature considerations

Importance of the Maximum Pipe Span Chart

Using an accurate maximum pipe span chart ensures:

- Structural safety:** Prevents pipe sagging, cracking, or breaking.
- System efficiency:** Maintains proper flow and reduces pressure loss.
- Compliance:** Meets building codes and standards.
- Cost-effectiveness:** Avoids over-supporting, reducing material costs.
- Longevity:** Extends the lifespan of the piping system.

Factors Influencing Maximum Pipe Span

Several factors impact the maximum allowable span for pipes:

- Pipe Material**
Different materials have varying strengths and flexibility: Steel pipes (e.g., carbon steel, stainless steel) generally support larger spans. Plastic pipes (PVC, CPVC, PEX) are more flexible and require closer supports. Copper pipes have moderate support requirements.
- Pipe Diameter and Thickness**
Larger diameters and thicker walls can bear more load but may also be heavier, influencing support spacing.
- Load Conditions**
Full load: When the pipe is filled with fluid.
Partial load: When the pipe is only partially filled. The weight of the fluid and pipe material impacts support requirements.
- Temperature**
Higher temperatures can cause expansion, requiring adjustments in support spacing.
- Support Type and Material**
Clamps, hangers, and brackets vary in strength and influence the maximum span.

Standard Guidelines for Pipe Spanning

Various organizations and codes provide guidelines for pipe support spacing. Here are some common standards:

- Steel Pipes (e.g., Black Steel, Galvanized)**

Pipe Size	Support Spacing (Maximum)	Reference Standard
1/2"	3-4 ft	ASME B36.10 / B36.19
1"	4-5 ft	ASME B36.10 / B36.19
2"	5-6 ft	ASME B36.10 / B36.19

[Note: Larger diameters may require supports at closer intervals due to increased weight.]
- PVC and Plastic Pipes**

Pipe Size	Support Spacing (Maximum)	Reference Standard
1/2"	3-4 ft	ASTM D1785, UPC
1"	4-5 ft	ASTM D1785, UPC
2"	4-6 ft	ASTM D1785, UPC

[Note: Plastic pipes are more flexible, so support spacing is slightly more forgiving but still requires adherence to standards.]
- Copper Pipes**

Pipe Size	Support Spacing (Maximum)	Reference Standard
1/2"	3-4 ft	Copper Tube Handbook
1"	4-5 ft	Copper Tube Handbook

Creating a Pipe

Span Chart: Step-by-StepTo develop a custom maximum pipe span chart tailored to specific project needs, follow these steps:

Identify Pipe Material and Size: Determine the pipe type and diameter.

Assess Load Conditions: Calculate the total weight, including fluid and pipe material.

Consult Standards and Codes: Use established guidelines from ASME, ASTM, UPC, or other relevant standards.

Determine Support Type: Decide on the type of support (e.g., rigid, flexible) and support material.

Calculate Support Spacing: Using the data and load calculations, determine the maximum span that maintains safe deflection limits.

Document and Verify: Record the span distances and verify against industry standards and manufacturer recommendations.

Practical Applications of the Maximum Pipe Span ChartThe maximum pipe span chart is used across various industries:

- 1. Building Plumbing Systems**Ensuring proper support spacing in residential, commercial, and industrial plumbing to prevent sagging and leaks.
- 2. Fire Protection Systems**Supporting large-diameter pipes in sprinkler systems to maintain system integrity.
- 3. HVAC Ductwork and Piping**Designing support systems that accommodate thermal expansion and vibration.
- 4. Industrial Piping**Supporting process pipes carrying chemicals, gases, or high-temperature fluids.
- 5. Infrastructure Projects**Designing large-scale pipelines for water, sewage, or oil transportation.

Common Mistakes to Avoid When Using Pipe Span ChartsWhile using maximum pipe span charts, it's important to avoid common pitfalls:

Ignoring load variations: Failing to account for full fluid load or additional weight.

Not considering thermal expansion: Overlooking temperature effects can lead to unsupported expansion or contraction.

Using outdated standards: Always verify that the chart aligns with current codes and standards.

Overlooking support quality: Poor support materials or installation can compromise support effectiveness.

Neglecting local building codes: Always verify compliance with local regulations.

ConclusionThe maximum pipe span chart is an indispensable tool for ensuring the safety, efficiency, and durability of piping systems. By understanding the factors influencing support spans and adhering to established standards, professionals can design piping systems that meet safety requirements and operational needs. Always consult relevant standards and manufacturer recommendations when developing or applying a pipe span chart to ensure compliance and optimal performance. Proper support spacing not only safeguards the structural integrity of the piping but also contributes to the overall success of construction and maintenance projects. Whether working with steel, plastic, or copper pipes, a detailed and accurate maximum pipe span chart is essential for effective and compliant piping system design. Remember: Regularly update your knowledge base with the latest standards and technological advancements to ensure your piping systems are built to the highest safety and performance standards.

Maximum Pipe Span Chart: An Expert Guide to Optimal Pipe Support and DesignWhen designing plumbing, HVAC, or industrial piping systems, understanding how to properly support pipes is crucial for safety, efficiency, and longevity. The Maximum Pipe Span Chart serves as an essential reference tool for engineers, contractors, and maintenance professionals, providing critical data on the maximum allowable distances between pipe supports based on various factors. This article

offers an in-depth exploration of the maximum pipe span chart, its significance, how to interpret it, and practical applications in piping system design.

What Is a Maximum Pipe Span Chart?A Maximum Pipe Span Chart is a comprehensive diagram or table that specifies the maximum permissible distances between supports or hangers for pipes of different sizes, materials, and operating conditions. It ensures that pipes are adequately supported to prevent sagging, deformation, or failure under their own weight, internal pressure, or external loads.

Purpose and Importance
Structural Integrity: Proper support minimizes stress on pipes, preventing deformation or rupture.
Safety Compliance: Ensures adherence to building codes and standards such as the International Mechanical Code (IMC) or ASME B31.1/B31.3.
Cost Efficiency: Optimizes the number of supports, balancing material costs with safety margins.
System Longevity: Proper support reduces wear and tear, extending the lifespan of piping systems.

Factors Influencing the Chart
Pipe material (e.g., steel, copper, PVC)
Pipe size (diameter and wall thickness)
Pipe type (e.g., rigid, flexible)
Operating temperature and pressure
External loads (e.g., insulation, vibrations)
Installation method (e.g., hung from ceiling, supported on brackets)

Understanding the Components of the Pipe Span Chart
The maximum pipe span chart is typically organized into sections based on pipe diameter, material, and application. The key components include:

- Pipe Size and Diameter** Larger diameter pipes generally require more frequent supports due to increased weight. The chart lists standard pipe sizes, often in inches or millimeters.
- Support Spacing (Span)** This indicates the maximum distance between supports, usually in feet or meters. Exceeding these distances risks pipe deflection or damage.
- Pipe Material** Different materials have varying strengths and thermal properties, influencing support requirements:
 - Steel and cast iron: high strength, longer spans
 - Copper: moderate strength
 - PVC and plastic: lower strength, shorter spans
- Operating Conditions** Temperature and pressure affect pipe flexibility and support needs. For example, hot water pipes may require closer supports due to thermal expansion.
- Support Type** The chart may specify support types like clamps, hangers, or brackets, which can influence allowable spans.

How to Read and Interpret a Maximum Pipe Span Chart
Proper interpretation of the chart involves understanding the relationship between pipe size, material, and support spacing. Here's a step-by-step guide:

- Step 1: Identify Pipe Size and Material** Locate the specific pipe diameter and material in the chart. For example, a 2-inch galvanized steel pipe.
- Step 2: Determine Operating Conditions** Assess whether the pipe carries hot or cold fluids, as this impacts support distance due to thermal expansion.
- Step 3: Find Corresponding Support Span** Match the pipe's operational parameters to the recommended maximum span. For instance, the chart may recommend supports every 10 feet for a 2-inch steel pipe.
- Step 4: Consider External Factors** Adjust spans based on additional loads (insulation, vibration), which may necessitate shorter supports.
- Step 5: Apply Support Spacing in Design** Use the chart data to plan support placement, ensuring compliance with safety and code standards.

Sample Maximum Pipe Span Chart Overview
While actual charts vary depending on standards and manufacturers, a typical maximum pipe span chart might look like this:

Pipe Diameter		Material		Max Support Spacing (ft)		Notes	
1/2 inch		Steel		8		For standard temperature and pressure	
1 inch		Copper		4		Adjust for thermal expansion	
2 inches		PVC		2		Shorter	

spans due to material strength|| 3 inches | Cast Iron | 10 | Suitable for heavy-duty applications |Note: These values are illustrative; consult specific standards for precise data.

Standards and Guidelines for Pipe Support Spacing

Several organizations establish standards for pipe support spacing, including:

- ASME B31.1 and B31.3** Provide detailed guidelines for power and process piping. Specify support spacing based on pipe size, material, and operating conditions.
- International Mechanical Code (IMC)** Contains requirements for pipe supports in building systems. Emphasizes safety and fire protection.
- Manufacturer Recommendations** Some pipe manufacturers provide specific support guidelines tailored to their products.

Key Points from Standards

Supports should be placed at intervals not exceeding the maximum span. For flexible piping (e.g., plastic), supports may need to be closer. Special considerations apply for horizontal, vertical, or inclined pipe runs.

Practical Applications of the Maximum Pipe Span Chart

Understanding and utilizing the chart effectively impacts various aspects of piping system design:

- New Installations** Ensures supports are correctly spaced from the outset, reducing future maintenance costs. Helps in planning support locations during layout design.
- System Modifications** When upgrading or modifying existing systems, refer to the chart to evaluate if current supports are adequate.
- Maintenance and Inspection** Regular inspections should verify support integrity and adherence to recommended spans.
- Energy Efficiency** Proper support reduces vibrations and leaks, contributing to system efficiency.
- Code Compliance and Certification** Using the chart ensures compliance with legal and safety standards, facilitating inspections and certifications.

Limitations and Considerations

While the maximum pipe span chart is a vital tool, it isn't exhaustive. Users should consider:

- Material Variations:** Different brands or manufacturing processes may affect strength.
- Environmental Conditions:** Exposure to seismic activity, wind, or corrosive environments may require additional supports.
- Thermal Expansion:** Hot water or steam lines may need supports that accommodate expansion and contraction.
- Vibration and Movement:** Machinery or external sources can necessitate closer supports.
- Aesthetic and Accessibility Requirements:** Support placement should balance functional and visual considerations.

Conclusion: The Significance of the Maximum Pipe Span Chart in Piping Design

The Maximum Pipe Span Chart is more than just a reference; it is a foundational tool underpinning the safety, efficiency, and durability of piping systems. Proper understanding and application of the chart help prevent structural failures, ensure compliance with code standards, and optimize material use. For engineers, contractors, and maintenance teams, familiarity with the chart's data ensures informed decision-making during installation and maintenance. As piping systems evolve with new materials and technologies, staying updated with current standards and manufacturer guidelines remains essential. In essence, leveraging the maximum pipe span chart is a best practice that safeguards investments, protects lives, and guarantees the reliable operation of piping infrastructure for years to come.

QuestionAnswer

What is a maximum pipe span chart and why is it important?

A maximum pipe span chart illustrates the maximum allowable span between supports for pipes of different sizes and materials, ensuring safe and efficient piping system design by preventing excessive deflection or failure.

How do I interpret a maximum pipe span chart?

To interpret a maximum pipe span chart, locate the pipe diameter and material, then read across to find the corresponding maximum span length between supports, which helps determine proper support placement in your installation.

What factors influence the maximum span of a pipe?

Factors include pipe material, diameter, wall thickness, fluid type and pressure, temperature, and support type, all of which affect how far a pipe can span safely without excessive deflection or damage.

Can a maximum pipe span chart be used for all pipe materials?

No, different pipe materials have different strength and flexibility characteristics; therefore, maximum span charts are specific to each material type and should be used accordingly.

How does pipe diameter affect the maximum span according to the chart?

Generally, larger diameter pipes require shorter spans between supports due to increased weight and potential deflection, which is reflected in the chart by decreasing maximum span values as diameter increases.

Are maximum pipe span charts applicable to both indoor and outdoor piping systems?

Yes, but it's important to select the chart that matches the specific conditions, including environmental factors, pipe material, and installation type, to ensure accurate support spacing recommendations.

What are the consequences of exceeding the maximum span indicated on the chart?

Exceeding the maximum span can lead to excessive pipe deflection, sagging, stress, or failure, which may cause leaks, pipe damage, or system failure, compromising safety and performance.

Where can I find reliable maximum pipe span charts for different pipe materials?

Reliable charts can be obtained from manufacturer catalogs, industry standards such as ASME or ASTM, plumbing codes, or specialized piping design software that reference approved support spans.

How often should support spacing be checked or updated based on maximum pipe span charts?
Support spacing should be checked during installation and periodically inspected during maintenance to ensure compliance with the maximum span guidelines, especially if pipe conditions or system requirements change.

Related keywords: pipe span chart, pipe span calculator, pipe span distance, pipe support guide, pipe load capacity, maximum pipe length, pipe support spacing, pipe stress chart, pipe installation guidelines, allowable pipe span

Liquid nitrogen pipe sizing chart

Liquid Nitrogen Pipe Sizing Chart: An Essential Guide for Safe and Efficient Cryogenic Systems

Liquid nitrogen pipe sizing chart is a critical resource for engineers, technicians, and facility managers involved in designing, installing, and maintaining cryogenic systems. Proper pipe sizing ensures the safe, efficient, and reliable transfer of liquid nitrogen (LN₂), minimizing risks such as pressure build-up, leaks, or system failure. This comprehensive guide will explore the fundamental aspects of liquid nitrogen pipe sizing, including key considerations, calculation methods, standards, and how to utilize a pipe sizing chart effectively.

Understanding Liquid Nitrogen and Its Cryogenic Properties

Before diving into pipe sizing specifics, it's essential to understand the nature of liquid nitrogen and its behavior in piping systems.

What is Liquid Nitrogen? Liquid nitrogen is a cryogenic fluid stored at extremely low temperatures (-196°C or -321°F). It is widely used in medical applications, food processing, cryopreservation, and industrial processes due to its inertness and rapid cooling capabilities.

Key Properties Affecting Pipe Sizing

- Low Temperature:** Causes materials to become brittle; influences insulation choices.
- High Vaporization Rate:** LN₂ tends to vaporize when exposed to higher temperatures, creating pressure that must be managed.
- Pressure and Flow Rate:** Systems operate under various pressures; flow rate determines pipe diameter requirements.

Importance of Proper Pipe Sizing in Liquid Nitrogen Systems

Accurate pipe sizing is vital for several reasons:

- Safety:** Prevents overpressure scenarios leading to pipe rupture.
- Efficiency:** Ensures minimal pressure drops, maintaining consistent flow.
- Cost-Effectiveness:** Avoids unnecessary material expenses or oversized piping.
- Compliance:** Meets industry standards and safety regulations.

Factors Influencing Liquid Nitrogen Pipe Sizing

Several parameters impact the appropriate pipe diameter for LN₂ systems:

- Flow Rate (Q):** Volume of liquid nitrogen transferred per

unit time (e.g., liters per minute or gallons per minute). Higher flow rates require larger diameters to reduce velocity and pressure loss. Length of Pipe Run Longer pipe runs increase the pressure drop. Proper sizing accounts for the total length to maintain desired flow and pressure. Velocity of Nitrogen Recommended velocity typically ranges between 2-10 m/sec (6.5-32.8 ft/sec). Excessively high velocity causes erosion and noise. Pressure Drop The acceptable difference between inlet and outlet pressures. Sizing aims to keep pressure drops within safe and operational limits. Vaporization and Boil-Off Rate Vaporization causes pressure increase; piping must accommodate vapor flow and venting. Insulation and Thermal Losses Proper insulation reduces vaporization and influences system pressure dynamics.

How to Use a Liquid Nitrogen Pipe Sizing Chart A liquid nitrogen pipe sizing chart provides a visual or tabular reference to select appropriate pipe diameters based on flow rate, pipe length, and acceptable pressure drops.

Step-by-Step Guide:

- Determine System Parameters:** Calculate or obtain the expected flow rate. Measure the total pipe length. Define acceptable pressure loss or velocity.
- Identify Operating Conditions:** Operating pressure. Vaporization rate.
- Select the Chart:** Use a chart that correlates flow rate and pipe diameter with pressure drop or velocity.
- Match Data Points:** Find the intersection points on the chart that match your flow rate and length. Choose the pipe diameter that maintains flow within safe velocity and pressure limits.
- Confirm with Calculation:** Cross-verify with detailed calculations or CFD analysis if necessary.

Standard Guidelines and Industry Practices for Pipe Sizing Several standards and best practices inform pipe sizing decisions:

- Industry Standards:** ASHRAE (American Society of Heating, Refrigerating and Air-Conditioning Engineers): Offers guidelines for cryogenic piping. ISO Standards: Provide international specifications for cryogenic systems. NFPA (National Fire Protection Association): Safety standards for cryogenic fluids.
- Recommended Practices:** Maintain velocities below 10 m/sec to prevent erosion. Use larger diameters for higher flow rates to minimize pressure drops. Incorporate expansion joints and relief valves to handle vaporization pressure. Ensure insulation is compatible with cryogenic temperatures.

Calculating Pipe Size for Liquid Nitrogen Systems While charts are useful, detailed calculations ensure precise sizing. Here are common approaches:

Darcy-Weisbach Equation Used to estimate pressure drop (ΔP):
$$\Delta P = \frac{f L \rho v^2}{2 D}$$
 Where: f = Darcy friction factor L = length of pipe ρ = density of LN v = velocity D = pipe diameter

Basic Steps: Determine flow rate (Q) and convert to velocity: $v = \frac{Q}{A}$ where A is the cross-sectional area. Calculate pressure drop based on the desired velocity and pipe length. Select a pipe diameter that keeps the velocity within recommended limits and pressure drop acceptable.

Use of Empirical Data and Software Many manufacturers provide pipe sizing software. Empirical charts can be consulted for quick reference.

Designing a Cryogenic Piping System: Practical Tips

- Material Selection:** Use materials compatible with cryogenic temperatures, such as stainless steel.
- Insulation:** Proper insulation reduces vaporization and maintains system pressure.
- Vapor Management:** Incorporate vapor vents or relief valves.
- Safety Measures:** Install pressure relief devices and sensors.
- Maintenance Access:** Design for ease of inspection and repair.

Summary: Key Takeaways for Liquid Nitrogen Pipe Sizing Always base pipe sizing on accurate flow rate and system length data. Maintain flow velocities within recommended ranges to prevent erosion and noise. Minimize pressure drops to ensure consistent flow and system safety. Use a liquid nitrogen pipe sizing chart as a quick reference, complemented by detailed

calculations. Follow industry standards and best practices for materials, insulation, and safety devices. **Conclusion** A liquid nitrogen pipe sizing chart is an indispensable tool in the design and operation of cryogenic systems. Proper sizing ensures safety, efficiency, and cost-effectiveness, enabling smooth transfer of LN₂ across various applications. By understanding the fundamental factors influencing pipe sizing, utilizing industry standards, and performing precise calculations, engineers can develop robust cryogenic piping systems that meet operational demands and safety regulations. **Additional Resources** Cryogenic Piping Design Guidelines ? ASHRAE Handbook ISO 21005: Cryogenic Liquefied Gases ? Piping and Equipment Manufacturer Technical Datasheets for cryogenic piping materials Cryogenic System Design Software ? such as AutoPIPE or PipeFlow Remember: Always consult with experienced cryogenic engineers and adhere to local safety standards when designing or modifying liquid nitrogen piping systems.

Liquid nitrogen pipe sizing chart: A comprehensive guide to ensuring safe, efficient, and cost-effective transfer of cryogenic fluids. When designing systems that involve the transportation of liquid nitrogen, one of the critical considerations is selecting the appropriate pipe size. The liquid nitrogen pipe sizing chart serves as an essential tool for engineers, designers, and safety professionals to determine the correct pipe diameters based on flow rates, pressure drops, insulation requirements, and safety margins. Proper pipe sizing not only optimizes system performance but also minimizes energy consumption, reduces the risk of leaks or failures, and ensures compliance with safety standards. In this guide, we will explore the fundamental principles of liquid nitrogen pipe sizing, introduce key factors influencing pipe selection, review how to interpret and utilize a liquid nitrogen pipe sizing chart, and provide practical tips for designing efficient cryogenic transfer systems.

Understanding Liquid Nitrogen Systems and the Need for Proper Pipe Sizing Liquid nitrogen is a cryogenic fluid stored and transported at extremely low temperatures (-196°C or -321°F). Its unique properties demand specialized piping systems that can handle: Extremely low temperatures, High flow velocities, Pressure differentials, Thermal insulation requirements. Inadequate pipe sizing can lead to issues such as excessive pressure drops, increased boil-off, or even pipe failure. Conversely, oversized pipes may increase initial costs and space requirements without proportional benefits.

Key Factors Influencing Liquid Nitrogen Pipe Sizing Before consulting a pipe sizing chart, it is crucial to understand the variables that affect pipe dimensioning:

- Flow Rate (Q)** The volume of liquid nitrogen to be transported per unit time, typically expressed in liters per minute (L/min) or gallons per minute (GPM). The required flow rate influences the pipe diameter; higher flow rates generally require larger pipes.
- Velocity (V)** Flow velocity affects pressure drop and turbulence. For cryogenic fluids like liquid nitrogen, velocities are usually kept within a safe range (e.g., 1 to 3 m/s) to minimize pressure loss and prevent pipe erosion.
- Pressure Drop (ΔP)** The difference in pressure between the pipe inlet and outlet. Excessive pressure drops can cause flow issues or require higher pump power. The pipe size should be chosen to keep pressure drops within acceptable limits.
- Pipe Material and Wall Thickness** Materials such as stainless steel or specialized alloys are common for cryogenic lines, with wall thickness influencing internal

diameter and insulation requirements. Insulation and Thermal Losses Since liquid nitrogen is extremely cold, proper insulation is vital. The pipe's insulation impacts the overall diameter and sometimes the choice of pipe size to compensate for thermal expansion or boil-off.

How to Use a Liquid Nitrogen Pipe Sizing Chart

A liquid nitrogen pipe sizing chart is a visual tool that correlates flow rates with appropriate pipe diameters based on pressure drops, velocity limits, and insulation considerations. Here's a step-by-step approach to using it effectively:

Step 1: Define System Parameters

- Determine the maximum flow rate needed (e.g., 10 L/min).
- Establish acceptable velocity ranges (commonly 1-3 m/s).
- Set maximum allowable pressure drop (e.g., 0.1 bar or 1.5 psi).
- Identify the inlet and outlet pressure conditions.

Step 2: Consult the Chart

Locate the flow rate on the chart's horizontal axis. From this point, move vertically to find the recommended pipe diameters that correspond to the desired velocity and pressure drop constraints.

Step 3: Select the Optimal Pipe Diameter

Choose the pipe size that balances:

- Adequate flow capacity
- Acceptable pressure drops
- Material and insulation considerations
- Cost efficiency

Step 4: Verify Compatibility with System Design

Ensure the selected pipe diameter aligns with other system components, such as pumps, valves, and insulation setup.

Common Pipe Sizes for Liquid Nitrogen Systems

The typical pipe diameters used in cryogenic liquid nitrogen systems range from small bore piping (e.g., 1/4 inch or 6 mm) for transfer lines to larger diameters (up to 4 inches or 100 mm) for bulk transport. Here's an overview:

- Small lines (1/4 inch - 1 inch):** Suitable for laboratory-scale or localized transfer.
- Medium lines (1.5 inches - 2 inches):** Common for industrial applications with moderate flow rates.
- Large lines (3 inches and above):** Used in facility-wide distribution or high-volume transfer.

Practical Tips for Pipe Sizing in Liquid Nitrogen Systems

- Prioritize safety:** Incorporate pressure relief valves and appropriate insulation to prevent condensation or frost buildup.
- Account for thermal contraction:** Materials may contract at cryogenic temperatures; select pipe materials accordingly.
- Plan for future expansion:** Consider slight oversizing if system capacity may increase.
- Use standard charts and software tools:** Many manufacturers provide detailed sizing charts, and specialized software can simulate complex flow scenarios.
- Consult codes and standards:** Ensure compliance with standards such as ASME B31.3 or ISO 21009 for cryogenic piping.

Summary: Key Takeaways on Liquid Nitrogen Pipe Sizing

The liquid nitrogen pipe sizing chart helps determine the optimal pipe diameter based on flow rate, pressure drop, and velocity constraints. Proper sizing enhances system efficiency, safety, and cost-effectiveness. Always define system parameters clearly before consulting the chart. Maintain safety margins and adhere to relevant standards. Regularly review and update pipe sizing as system demands evolve.

Final Thoughts

Designing a reliable liquid nitrogen transfer system hinges on choosing the right pipe size. The liquid nitrogen pipe sizing chart is an invaluable resource that simplifies this process, enabling engineers to make informed decisions that balance performance, safety, and cost. Whether you are setting up a small laboratory line or a large industrial cryogenic network, understanding how to interpret and apply pipe sizing charts will ensure your system operates smoothly and safely for years to come.

Disclaimer: Always consult with a qualified engineer or cryogenic specialist when designing or modifying liquid nitrogen piping systems. Proper installation, insulation, and safety measures are crucial for cryogenic applications.

QuestionAnswer

What factors should be considered when selecting a liquid nitrogen pipe size?

Key factors include flow rate requirements, pipe length, insulation type, allowable pressure drop, and operating temperature to ensure efficient transfer and safety.

How does pipe diameter affect liquid nitrogen flow and pressure loss?

Larger diameters reduce pressure loss and allow higher flow rates with less velocity, whereas smaller diameters increase pressure drop and may cause turbulence, impacting system efficiency.

Where can I find a reliable liquid nitrogen pipe sizing chart?

Reliable charts are available from manufacturers, industry standards organizations like ASME, or engineering software tools designed for cryogenic piping systems.

Why is it important to follow a pipe sizing chart specifically for liquid nitrogen?

Because liquid nitrogen is cryogenic, it requires precise sizing to prevent issues like excessive pressure drop, leaks, or safety hazards caused by improper pipe dimensions.

Can a liquid nitrogen pipe sizing chart help optimize system performance?

Yes, it helps ensure the correct pipe dimensions are used, minimizing energy loss, avoiding over-sizing or under-sizing, and enhancing overall system safety and efficiency.

How do temperature and pressure conditions influence liquid nitrogen pipe sizing?

Temperature and pressure conditions affect the fluid's density and viscosity, which are critical parameters in the sizing chart to ensure accurate flow and pressure management.

Related keywords: liquid nitrogen pipeline dimensions, cryogenic pipe sizing, nitrogen transfer line calculation, cryogenic piping chart, liquid nitrogen flow rate, cryogenic pipe diameter, nitrogen piping standards, cryogenic system design, liquid nitrogen transfer efficiency, cryogenic piping specifications

Pipe support span calculation

Pipe support span calculation is a critical aspect of piping system design that ensures safety, integrity, and longevity of the piping infrastructure. Proper support placement prevents excessive deflection, reduces stress on pipes, minimizes vibration, and helps maintain the system's operational efficiency. Whether designing for industrial plants, residential plumbing, or high-pressure systems, understanding how to accurately calculate and determine the appropriate span between pipe supports is essential for engineers, designers, and maintenance personnel.

Importance of Pipe Support Spans

Proper pipe support span calculation is fundamental for several reasons:

- Preventing Pipe Deformation:** Excessive span can lead to bending and deformation under the weight of the pipe and contained fluids.
- Reducing Stress and Fatigue:** Proper support minimizes stress concentrations that could cause cracks or failures over time.
- Controlling Vibration and Noise:** Correct support placement dampens vibrations, which are especially critical in high-flow systems.
- Ensuring Compliance:** Many codes and standards specify maximum allowable spans to ensure safety and reliability.

Factors Influencing Pipe Support Span Calculation

Effective calculation depends on multiple factors, which include:

- Pipe Material:** Steel, PVC, copper, and other materials have different flexural strengths.
- Pipe Diameter and Thickness:** Larger and thicker pipes are more rigid but also heavier.
- Pipe Weight:** Includes the weight of the pipe itself plus the contents.
- Support Type:** Fixed, sliding, or spring supports influence how loads are distributed.
- Fluid Characteristics:** Viscosity, flow rate, and temperature can affect pipe behavior.
- Environmental Conditions:** External factors like temperature fluctuations, wind, and seismic activity.

Standards and Guidelines for Pipe Support Spans

Several standards govern pipe support span calculations, ensuring uniformity and safety:

- ASME B31.3 (Process Piping):** Provides guidelines for support spacing based on pipe size and material.
- API Standards:** For oil and gas pipelines, API standards specify support practices.
- ISO Standards:** Offer international guidelines for piping support and installation.
- Local Building Codes:** May impose additional requirements depending on jurisdiction.

Calculating Pipe Support Spans: Step-by-Step Approach

Calculating pipe support spans involves a systematic process. Here's a detailed methodology:

- Step 1: Gather Essential Data**

Before starting calculations, collect:

 - Pipe material and specifications (diameter, wall thickness)
 - Pipe length and configuration
 - Pipe and fluid weight
 - Support type and positioning constraints
 - Environmental and operational conditions
- Step 2: Determine Pipe Weight**

Calculate the weight of the pipe per unit length:

$$W_{\text{pipe}} = \text{Material density} \times \text{Volume per unit length}$$

For a circular pipe:

$$W_{\text{pipe}} = \rho_{\text{material}} \times \pi \times \left(R_{\text{outer}}^2 - R_{\text{inner}}^2 \right)$$

where: R_{outer} = outer radius, R_{inner} = inner radius

Add the weight of the contained fluid if significant.
- Step 3: Identify Maximum Allowable Deflection**

Design standards specify permissible deflection limits, often expressed as a fraction of the span or pipe diameter, such as:

 - 1/200 of the span
 - 1/20 of the span for certain applications

This limit ensures the pipe maintains its structural integrity and operational efficiency.
- Step 4: Select Suitable Support Types**

Support types influence span calculations:

 - Rigid Supports:** Fixed or anchored supports with minimal movement.
 - Sliding Supports:** Allow for thermal expansion and contraction.
 - Spring Supports:** Absorb loads dynamically.

The support choice affects the maximum span, as some supports can handle longer spans due to flexibility.
- Step 5: Calculate Support Span**

Using Flexural and Load Data Using beam theory principles, the maximum span (L) can be estimated with the formula:
$$L = \left(\frac{K \times E \times I \times \delta_{\max}}{W_{\text{total}}} \right)^{1/4}$$
 where: (K) = a constant depending on support conditions (E) = modulus of elasticity of pipe material (I) = moment of inertia ($\delta_{\max}$) = maximum permissible deflection (W_{total}) = total load per unit length

Alternatively, for practical purposes, industry tables and software tools are often used to determine spans based on empirical data aligned with standards.

Practical Guidelines and Typical Support Spans

While precise calculations are necessary for critical systems, general guidelines for support spans are:

- Steel Pipes:** Typically support every 3 to 6 meters (10 to 20 feet) depending on diameter and thickness.
- PVC and Plastic Pipes:** Usually supported every 1.5 to 3 meters (5 to 10 feet).
- High-Temperature or High-Pressure Systems:** Require closer supports, sometimes every 1 to 2 meters (3 to 6 feet).

Always consult relevant standards for specific applications, as these figures can vary based on conditions.

Design Considerations for Optimal Pipe Support Spans

In addition to calculation accuracy, consider the following for robust piping systems:

- Thermal Expansion:** Include expansion loops or flexible supports.
- Accessibility:** Ensure supports allow easy inspection and maintenance.
- Vibration Control:** Use damping supports or isolators if needed.
- Load Distribution:** Avoid concentrated loads that could overstress supports.
- Corrosion and Wear:** Choose durable support materials compatible with pipe material and environment.

Common Tools and Software for Support Span Calculation

Modern engineering leverages technology for accurate and efficient calculations:

- Finite Element Analysis (FEA) Software:** ANSYS, SAP2000, or specialized piping analysis tools.
- Support Spacing Tables:** Published in standards and handbooks.
- Spreadsheet Models:** Custom spreadsheets tailored to specific project requirements.
- CAD Integration:** Supports visualization and dynamic adjustment of support locations.

Conclusion: Ensuring Safety and Reliability Through Proper Support Span Calculation

Accurate pipe support span calculation is a cornerstone of effective piping system design. It combines fundamental engineering principles, industry standards, and practical experience to determine optimal support placement. By thoroughly analyzing factors such as pipe weight, material properties, environmental conditions, and support types, designers can prevent structural failures, reduce maintenance costs, and ensure compliance with safety regulations. Employing proper calculation methods and leveraging available tools ultimately leads to safer, more durable, and efficient piping systems that serve their intended purpose reliably over their operational lifespan.

References and Further Reading

- ASME B31.3 Process Piping Code
- API Standard 650 Welded Tanks for Oil Storage
- ISO 14692 Petroleum and natural gas industries ? Glass-reinforced plastics piping
- "Piping Design and Engineering" by M. S. Ramachandra Rao

Industry support span tables and guidelines from piping material manufacturers

Remember: Accurate support span calculation is not just about adhering to standards; it's about ensuring safety, efficiency, and longevity of your piping infrastructure. Always verify calculations with current standards and consult experienced engineers when designing critical systems.

Pipe support span calculation is a fundamental aspect of piping design and installation, ensuring the

structural integrity, safety, and longevity of piping systems. Properly calculating the support span helps prevent sagging, excessive deflection, and potential failure of pipes under various load conditions. Whether you're an engineer, designer, or installer, understanding how to accurately determine support spans is critical to maintaining compliance with codes and optimizing system performance.

Introduction to Pipe Support Span Calculation

Pipe support span calculation involves determining the maximum distance between supports for a pipe of specified material, diameter, and operating conditions. This calculation considers factors such as pipe weight, contents, environmental loads, and the type of support used. Proper support spans ensure that the pipe remains stable, minimizes stress concentrations, and adheres to safety standards.

Why Is Correct Support Span Important?

- Prevents sagging and deformation:** Excessive span can lead to pipe sagging, causing flow issues or mechanical stress.
- Reduces stress and fatigue:** Proper support reduces stress concentrations that could lead to fatigue failure over time.
- Maintains alignment and system integrity:** Properly supported pipes stay aligned, reducing wear and potential leaks.
- Ensures compliance:** Many codes and standards specify maximum support spans for different pipe sizes and materials.

Factors Influencing Pipe Support Span Calculation

Several key factors influence the calculation of pipe support spans, including:

- Pipe Material and Wall Thickness:** Different materials (e.g., carbon steel, stainless steel, plastic) have varying stiffness and weight, affecting how much they can span between supports.
- Pipe Diameter and Wall Thickness:** Larger diameter and thicker pipes are heavier and more prone to sagging, requiring shorter spans.
- Pipe Operating Conditions:**
 - Fluid type and pressure:** Pressurized or viscous fluids increase pipe weight and stress.
 - Temperature:** Elevated temperatures can cause expansion or softening, affecting support requirements.
- Support Type:** Hangers, clamps, saddle supports: Each provides different support characteristics.
- Fixed or sliding supports:** Influence allowable span due to movement allowances.
- Environmental Loads:** Wind, seismic activity, and thermal expansion: External factors that impose additional loads.

Relevant Codes and Standards

Standards such as ASME B31.3, ASME B31.1, and API 650 provide guidelines for maximum support spans.

Step-by-Step Guide to Pipe Support Span Calculation

Step 1: Gather Essential Data

Before starting the calculation, collect the following data:

- Pipe material and specifications (diameter, wall thickness)
- Pipe length and layout
- Operating temperature and pressure
- Contents (fluid type, density, viscosity)
- Support type and location
- Environmental loading conditions

Step 2: Determine Pipe Weight

Calculate the pipe weight per unit length considering:

- Pipe material density
- Wall thickness
- Inner and outer diameters

The general formula:

$$\text{Pipe weight per unit length (kg/m)} = \left(\frac{\pi}{4}\right) \times (D_o^2 - D_i^2) \times \text{density}$$

Where: D_o = outer diameter, D_i = inner diameter

Step 3: Include Content Weight

Add the weight of the fluid or contents inside the pipe:

$$\text{Content weight per unit length} = \text{fluid density} \times \text{cross-sectional area}$$

Step 4: Calculate Total Load

Total load per unit length:

$$\text{Total load} = \text{Pipe weight} + \text{Content weight} + \text{External loads (if any)}$$

Step 5: Refer to Design Standards and Tables

Consult relevant standards for maximum allowable spans based on pipe size, material, and support type. For example, ASME B31.3 provides tables and guidelines that specify maximum spans for various pipe sizes and materials.

Step 6: Perform Structural Analysis (if needed)

For complex systems or unusual conditions, perform a structural analysis considering:

- Bending moments
- Deflections
- Support reactions

Software tools or manual calculations involving beam theory can help determine the maximum allowable

span.Step 7: Determine Support SpansUsing the data and standards, select support spacing that:Does not exceed the maximum span suggestedAccounts for additional loads such as thermal expansion or seismic activityEnsures deflections stay within acceptable limits (often L/240 or L/180, where L is the span length)Supporting Data and ChartsMany manufacturers and standards organizations provide support span charts that give recommended maximum spans based on pipe diameter and material. These charts are valuable tools for quick reference and validation.Example: Typical Support Spans for Carbon Steel Pipe (ASME B31.3)| Pipe Diameter (inches) | Max Support Span (feet) ||-----|-----|| 1/2" | 3.0 | 1" | 4.0 | 2" | 6.0 | 4" | 8.0 | 6" | 10.0 |

[Note: Always verify with the latest code and manufacturer data.Practical Considerations in Support Span DesignThermal Expansion and ContractionPipes expand and contract with temperature changes. Supports should accommodate thermal movement without inducing excessive stress.Solutions include:Sliding supportsExpansion loopsFlexible hangersVibration and External LoadsIn environments with high vibration or external forces, supports must be robust enough to prevent pipe movement and fatigue.Accessibility and MaintenanceSupport placement should facilitate inspection, maintenance, and repair activities.Support Material and DesignSupports should be made of durable materials compatible with pipe material and operating environment.Common Support Types and Their Impact on Span CalculationHangers: Suspend pipe from overhead; typically used for vertical support.Saddle Supports: Support pipes on horizontal surfaces; suitable for larger diameters.Clamps and Straps: Provide secondary support; often used in combination with other supports.Spring Supports: Allow for thermal movement; critical in long runs with temperature variations.Each support type influences the maximum permissible span, with spring supports often allowing longer spans due to their flexibility.Final Tips and Best PracticesAlways adhere to the latest standards and manufacturer recommendations.Perform detailed calculations for critical or long-span pipes.Consider the worst-case scenario, including maximum fluid density, pressure, and temperature.Incorporate allowances for thermal expansion, movement, and external forces.Use support spacing as a part of a comprehensive piping stress analysis.ConclusionPipe support span calculation is a vital component of effective piping system design, balancing safety, functionality, and cost-efficiency. By systematically assessing pipe loads, material properties, environmental factors, and applicable standards, engineers can determine optimal support locations that ensure reliable operation over the system's lifespan. A thorough understanding of these principles not only helps prevent structural failures but also enhances the overall integrity of piping installations in diverse industrial applications.

QuestionAnswer

What is the purpose of calculating pipe support span?

Calculating pipe support span ensures the pipe's structural integrity, prevents excessive deflection, and maintains safety and functionality under various loads.

What factors influence the span calculation for pipe supports?

Factors include pipe diameter, material, weight (including contents), support type, allowable deflection, and environmental conditions such as temperature and vibration.

How do you determine the maximum span between pipe supports?

The maximum span is determined based on pipe diameter, material strength, allowable deflection limits, and applicable codes or standards, often using formulas or manufacturer guidelines.

Are there standard formulas for pipe span calculation?

Yes, standard formulas exist based on beam theory, such as the simple span formula considering pipe weight and allowable deflection, often supplemented by code-specific tables.

How does pipe material affect support span calculation?

Different materials have varying strength and flexibility; for example, steel pipes typically allow longer spans than plastic pipes due to higher strength and stiffness.

What role do support types play in span calculation?

Support types (e.g., hangers, brackets, rollers) influence allowable spans because different supports provide varying levels of restraint and load distribution.

How do temperature changes impact pipe support span calculations?

Temperature variations cause thermal expansion or contraction, which can affect deflection limits; spans may need to be reduced or supports designed to accommodate movement.

Are there industry standards or codes that provide guidelines for pipe support spans?

Yes, standards such as ASME B31.1, B31.3, and relevant API codes specify guidelines and maximum spans for different pipe sizes, materials, and conditions.

What tools or software are available for calculating pipe support spans?

Various engineering software like CAESAR II, PIPE-FLO, and AutoPIPE offer modules for pipe

stress analysis and span calculation, helping ensure compliance and safety.

Related keywords: pipe support span, pipe support design, pipe span calculation, pipe load analysis, support spacing, pipe engineering, structural support for pipes, piping system analysis, support placement, pipe stress analysis

Maximum allowable span for hdpe pipe

Maximum allowable span for hdpe pipe is a critical consideration in the design, installation, and maintenance of high-density polyethylene (HDPE) piping systems. Properly determining the span ensures the structural integrity, longevity, and safety of the pipeline, whether it is used for water supply, sewage, gas, or industrial applications. HDPE pipes are renowned for their flexibility, durability, and resistance to corrosion, making them a popular choice across various industries. However, even with these advantageous properties, improper span lengths can lead to unwanted stress, deformation, or failure. Therefore, understanding the maximum allowable span for HDPE pipes is essential for engineers, contractors, and project managers to optimize pipe performance and compliance with relevant standards.

Understanding HDPE Pipe Characteristics and Their Impact on Span

HDPE pipes are manufactured through a process that results in a semi-rigid yet highly flexible pipe material. This flexibility allows the pipe to withstand ground movements and minor shifts without cracking or breaking. However, it also means that the pipe's unsupported span must be carefully controlled to prevent sagging, deformation, or excessive stress on the pipe walls.

The key characteristics influencing the maximum allowable span include:

- Pipe diameter
- Pipe wall thickness (DR ? Dimension Ratio)
- Pipe material and grade
- Installation environment and load conditions
- Support conditions and bedding

These factors collectively determine the maximum span length that the pipe can safely sustain without additional supports or anchors.

Standards and Guidelines Governing HDPE Pipe Spans

Several national and international standards provide guidelines for the permissible spans of HDPE pipes. These standards aim to ensure safety, durability, and performance across different applications.

- ASTM International Standards**
 - ASTM F2164: "Standard Specification for Polyethylene (PE) Large Diameter Profile Wall and Solid Wall Pipe"
 - ASTM D3035: "Standard Specification for Polyethylene (PE) Plastic Pipe (DR-PR) Based on Outside Diameter"
- ISO Standards**
 - ISO 4437: "Polyethylene (PE) pipes and fittings for gas supply systems" ? includes guidelines for installation and support
 - ISO 4427: "Polyethylene pipes for water supply" ? specifies installation requirements including span considerations
- European Standards (EN)**
 - EN 12201: "Specifications for polyethylene pipes for water supply, drainage, and sewerage" ? addresses installation and support

Adherence to these standards helps ensure that HDPE piping systems are installed with appropriate spans that prevent structural issues and promote long-term performance.

Factors Influencing the Maximum Span for HDPE Pipes

Determining the maximum

span involves analyzing various factors:

Pipe Diameter and Thickness Larger diameter pipes generally require shorter spans due to increased bending moments and potential sagging. Similarly, thicker walls (lower DR ratios) provide greater stiffness, allowing for longer spans.

Load Conditions

Static Loads: Soil weight, traffic loads, or attached equipment can exert stress on the pipe.

Dynamic Loads: Vibrations, water hammer, or ground movement may impact span considerations.

Support Conditions and Bedding Proper bedding and support reduce bending stresses. The type of bedding (e.g., compacted granular material, concrete cradle) influences the maximum allowable span.

Environmental Conditions Exposure to temperature variations, UV radiation, or chemical environments can affect pipe flexibility and strength, thereby impacting span limits.

Typical Maximum Spans for HDPE Pipes While actual spans depend on specific project conditions and standards, typical values derived from engineering practices and guidelines are as follows:

Based on Pipe Diameter and Wall Thickness			
Pipe Diameter (mm)	Typical Max Span (m)	Notes	
63 - 160	1.5 - 3.0	Light loads, good bedding	
200 - 400	3.0 - 6.0	Moderate loads, proper bedding essential	
450 - 600	4.5 - 9.0	Heavy loads, reinforced bedding recommended	
700 - 1000	6.0 - 12.0	Industrial applications, support structures necessary	

[Note: These values are approximate and should always be verified against relevant standards and site-specific conditions.]

Design Considerations for Spanning HDPE Pipes Proper design is essential to optimize span lengths while maintaining safety and durability.

Calculating Bending Stress The bending stress in a pipe supported at regular intervals can be estimated using the formula:

$$\sigma_b = \frac{M \times c}{I}$$

Where:

- σ_b is the bending stress
- M is the bending moment
- c is the distance from neutral axis to outer fiber
- I is the moment of inertia

Design should ensure that the bending stress remains below the pipe's allowable stress limit.

Support Spacing and Bedding Design Use bedding materials with sufficient compaction to distribute loads evenly. Incorporate support intervals based on pipe size and load conditions. For large diameters or high loads, consider using concrete cradles or additional supports.

Allowances for Thermal Expansion HDPE pipes expand and contract with temperature changes. Spans should factor in thermal movement to prevent buckling or undue stress.

Installation Best Practices to Maximize Pipe Longevity Proper installation practices are vital for maintaining correct span lengths and ensuring the pipe's structural integrity.

Site Assessment: Evaluate soil conditions, load factors, and environmental influences.

Support Spacing: Follow manufacturer recommendations and standards for support intervals.

Bedding Preparation: Use suitable bedding materials and ensure proper compaction.

Handling and Placement: Avoid excessive bending or dragging during installation.

Testing and Inspection: Conduct pressure tests and visual inspections before backfilling. Adhering to these practices helps prevent issues related to overextended spans, such as sagging, deformation, or early failure.

Conclusion: Ensuring Optimal Pipe Performance Through Proper Span Management The maximum allowable span for HDPE pipe is a fundamental parameter that directly influences the durability, safety, and efficiency of piping systems. While the typical spans vary based on pipe size, material grade, support conditions, and environmental factors, industry standards and engineering best practices provide clear guidance to determine safe support intervals. Proper design, installation, and support strategies rooted in understanding the pipe's characteristics and the project's specific demands are essential for achieving a reliable and

long-lasting piping system. In summary: Always reference relevant standards such as ASTM, ISO, and EN for specific span guidelines. Consider all load and environmental factors during design. Use appropriate bedding and support systems. Regularly inspect and maintain installed pipelines to detect and address potential issues early. By carefully managing the maximum span for HDPE pipes, engineers and contractors can ensure that their systems operate effectively for decades, providing safe and sustainable infrastructure solutions.

Maximum Allowable Span for HDPE Pipe: An Expert Review

High-Density Polyethylene (HDPE) pipes have become the material of choice for diverse applications ranging from water supply and sewage systems to industrial and mining operations. Their durability, flexibility, and chemical resistance make them ideal for various demanding environments. One critical aspect that engineers, contractors, and project planners must consider when designing and installing HDPE piping systems is the maximum allowable span—the distance between supports or anchors that ensures the pipe's structural integrity, flow efficiency, and longevity. Understanding the maximum allowable span is essential to prevent issues such as sagging, undue stress, premature failure, or flow restrictions. This article delves deeply into what influences the span limits of HDPE pipes, providing comprehensive guidelines, engineering considerations, and practical insights to help professionals optimize their piping systems.

Understanding HDPE Pipe and Its Structural Characteristics

Before exploring span limitations, it's important to understand the fundamental properties of HDPE pipes that influence their support requirements.

What Is HDPE Pipe? HDPE pipes are made from high-density polyethylene resin, characterized by high tensile strength, excellent chemical resistance, and remarkable flexibility. Their seamless, corrosion-resistant construction makes them suitable for underground and pressurized systems.

Key Properties Affecting Span

Flexibility: HDPE pipes can bend without breaking, reducing the need for extensive supports in some cases.

Tensile Strength: While strong under tension, their ability to withstand bending stresses depends on diameter and wall thickness.

Elasticity: HDPE's elastic behavior allows it to deform under load and return to shape, but excessive bending or unsupported spans can lead to deformation.

Wall Thickness (DR Series): The dimension ratio (DR) impacts stiffness; higher DR (thinner walls) means more flexibility, influencing span limits.

Factors Influencing the Maximum Allowable Span

The maximum span of an HDPE pipe isn't arbitrary; it's governed by multiple interconnected factors that must be carefully evaluated during design. These include:

Pipe Diameter and Wall Thickness

Diameter: Larger diameters tend to be more susceptible to sagging unless supported adequately because of increased weight and bending moment.

Wall Thickness (or SDR - Standard Dimension Ratio): Thicker walls (lower SDR) provide greater stiffness, allowing longer spans without support.

Pipe Material and Grade

Different HDPE grades (e.g., PE80, PE100) have varying mechanical properties, especially tensile strength and stiffness. Higher grades generally permit longer unsupported spans due to improved load-bearing capacity.

Installation Environment

Buried vs. Above Ground: Buried pipes are supported by the surrounding soil, reducing the need for internal supports. Above-ground pipes require careful support design.

Soil Conditions: Stable, dense soils

provide better support; loose or variable soils may necessitate shorter spans. Temperature: Elevated temperatures can soften HDPE, reducing its load-carrying capacity and possibly decreasing maximum span. Internal Pressure and Flow Dynamics Internal Pressure: Higher internal pressures induce hoop and longitudinal stresses that influence permissible span. Flow Rate and Velocity: Rapid flow or high velocities can cause vibrations or pressure surges that impact support requirements. Support and Anchorage Design Properly designed supports, anchors, and restraints can significantly extend the feasible span, especially when considering dynamic loads and thermal expansion. Standards and Guidelines for HDPE Pipe Spans Multiple standards and industry guidelines provide recommendations for maximum spans, but these are often conservative estimates to ensure safety and longevity. International Standards Overview ISO 16133: Specifies testing and design considerations but offers limited direct span parameters. ASTM D3035: Provides properties and installation guidelines that impact span considerations. AWWA C906: Offers design and installation practices specifically for HDPE pressure pipes. DIN 8074/8075 and BS EN 12201: European standards with recommendations on support intervals based on pipe size and application. Industry-Recommended Spans Based on accumulated industry experience and standards, typical maximum unsupported spans are:

Pipe Diameter (mm)	Typical Maximum Span (m)	Notes
Up to 63 mm	3 to 4	Small pipes, often supported at shorter intervals
75 mm ? 160 mm	4 to 6	Moderate support intervals
200 mm ? 315 mm	6 to 9	Longer spans permissible with proper supports
355 mm ? 630 mm	9 to 12	Larger diameters, support design becomes critical
> 630 mm	12+	Requires detailed engineering analysis

[Note: These are general guidelines; actual spans depend on the factors outlined earlier.]

Engineering Calculations and Design Considerations Designing for maximum span involves detailed calculations considering load, pipe stiffness, and support conditions. Bending Stress and Deflection The primary concern when considering unsupported spans is the deflection under the pipe's own weight and operational loads. Maximum Allowable Deflection: Often limited to 5% of the pipe diameter to prevent excessive sagging. Calculation Approach:
$$\Delta = \frac{5wL^4}{384EI}$$
 Where: Δ : allowable deflection w : load per unit length (self-weight + additional loads) L : span length E : modulus of elasticity I : moment of inertia of the pipe cross-section By rearranging, engineers determine the maximum span L that keeps deflection within limits. Load Factors and Support Conditions Point Supports vs. Continuous Supports: Continuous supports distribute load more evenly, allowing longer spans. Support Type: Rigid supports (e.g., concrete blocks) vs. flexible supports (e.g., soil beds) influence allowable span. Thermal Expansion and Contraction HDPE's thermal movement can cause stress if spans are too long without allowances, leading to deformation or failure. Expansion Coefficient: Approximately (1.5×10^{-4}) /°C. Design Solution: Incorporate expansion joints or support points to accommodate movement. Soil and Environmental Conditions In buried applications, the surrounding soil provides support. However: Loose or Wet Soils: Require shorter spans or additional bedding. Rocky or Firm Soils: Permit longer unsupported spans. Practical Guidelines for Installing HDPE Pipes with Optimal Spans While theoretical calculations provide a foundation, practical

experience and field conditions often dictate support intervals.

General Best Practices

Support at Regular Intervals: Typically every 1.5 to 3 meters for small to medium pipes.

Specialized Supports for Large Diameter Pipes: For pipes over 315 mm, supports are often spaced every 6 to 12 meters, depending on load and environment.

Use of Cradles and Bedding: Proper bedding reduces stress and distributes loads evenly.

Thermal Considerations: In regions with significant temperature variation, supports should accommodate expansion.

Monitoring and Inspection: Periodic checks for sagging or deformation, especially in long spans.

Case Studies and Real-World Examples

Case Study 1: Urban Water Pipeline A city planning to install a 200 mm HDPE water pipeline above ground opted for supports every 8 meters. The supports consisted of concrete cradles designed to withstand soil movement and temperature fluctuations. The design adhered to the maximum span guidelines, ensuring minimal deflection and no flow issues.

Case Study 2: Industrial Drainage System An industrial facility used 315 mm HDPE pipes for drainage, supported every 10 meters with heavy-duty supports. The design accounted for high flow velocities and potential thermal expansion. The supports were engineered to accommodate movement, allowing longer spans without compromising system integrity.

Conclusion: Striking the Balance Between Support and Flexibility The maximum allowable span for HDPE pipes is not a fixed number but a carefully determined parameter influenced by multiple factors: diameter, wall thickness, material grade, environmental conditions, and installation practices. While industry guidelines offer a valuable starting point, the optimal design must incorporate detailed engineering calculations, site-specific conditions, and adherence to relevant standards.

In practice, well-planned support intervals ensure the longevity and reliable performance of HDPE piping systems, minimizing maintenance costs and preventing failures. As HDPE pipe technology advances and standards evolve, engineers must stay informed about best practices and innovative solutions to maximize span efficiency without compromising safety or functionality.

By understanding and applying the principles outlined in this review, professionals can design piping systems that leverage the full benefits of HDPE's flexibility and durability while respecting the critical limits of unsupported spans.

In summary: Support intervals for HDPE pipes vary based on diameter, wall thickness, and environment. Industry standards recommend spans ranging from 3 meters for small pipes up to over 12 meters for large ones, with detailed engineering analysis to confirm. Proper support design, environmental considerations, and adherence to standards are key to ensuring system integrity. Continuous evaluation and maintenance are essential for long-term performance. Maximizing the effectiveness of HDPE piping systems hinges on understanding the maximum allowable span?

QuestionAnswer

What is the maximum allowable span for HDPE pipes in residential irrigation systems?

The maximum allowable span for HDPE pipes in residential irrigation typically ranges from 4 to 6 meters, depending on pipe diameter and load conditions, as per manufacturer guidelines and local

standards.

How does pipe diameter affect the maximum allowable span for HDPE pipes?

Larger diameter HDPE pipes generally have a greater maximum allowable span due to their increased strength and stiffness, reducing the need for intermediate supports compared to smaller diameter pipes.

Are there specific codes or standards that define the maximum span for HDPE pipes?

Yes, standards such as ASTM D3035, ISO 4427, and local building codes provide guidelines on maximum spans, typically based on pipe size, load conditions, and installation environment.

How does soil load influence the maximum span of buried HDPE pipes?

Higher soil loads increase the pipe's deflection and stress, thereby reducing the maximum allowable span; proper bedding and backfill are essential to optimize span limits.

Can ambient temperature affect the maximum span of HDPE pipes?

Yes, elevated temperatures can soften HDPE material, potentially reducing its load-bearing capacity and thus decreasing the maximum allowable span to prevent deformation.

Is it necessary to support HDPE pipes at regular intervals for maximum span optimization?

Yes, supporting HDPE pipes at recommended intervals, often specified by manufacturers, helps prevent sagging and ensures structural integrity, especially over longer spans.

How do installation conditions influence the maximum span for HDPE pipes?

Factors such as bedding quality, load from traffic or machinery, and environmental conditions can reduce the maximum span, necessitating shorter supports or additional reinforcement.

What is the typical maximum span for large-diameter HDPE pipes used in municipal water systems?

For large-diameter HDPE pipes in municipal applications, spans can range from 10 to 20 meters or more, depending on specific design criteria, support methods, and manufacturer recommendations.

How can engineers determine the appropriate maximum span for HDPE pipes in a project?

Engineers should consider pipe diameter, material properties, load conditions, installation

environment, and applicable standards, often performing structural analysis or consulting manufacturer guidelines to determine suitable spans.

Related keywords: HDPE pipe span, maximum span length, pipe support spacing, allowable span distance, pipe load capacity, pipe installation guidelines, engineering standards HDPE, structural design HDPE pipe, load limits HDPE, pipeline span regulations

Nitrogen gas pipe sizing chart

nitrogen gas pipe sizing chart is an essential tool for engineers, technicians, and plant operators involved in designing, installing, and maintaining systems that utilize nitrogen gas. Proper pipe sizing ensures efficient flow, safety, and cost-effectiveness in various applications such as inerting, purge systems, pressurized storage, and industrial manufacturing processes. An accurate sizing chart helps determine the appropriate pipe diameter based on flow rate, pressure, and other operational parameters, thereby preventing issues such as pressure drops, flow restrictions, or over-pressurization. This comprehensive guide aims to explain the fundamentals of nitrogen gas pipe sizing, how to interpret and use a pipe sizing chart effectively, and important considerations for safe and efficient system design.

Understanding the Importance of Proper Nitrogen Gas Pipe Sizing

Proper pipe sizing in nitrogen systems is crucial for several reasons:

- Maintaining System Efficiency:** Correct pipe diameter ensures optimal flow rates, reducing energy consumption and operational costs.
- Preventing Pressure Drops:** Oversized or undersized pipes can cause undesirable pressure drops, affecting process performance.
- Ensuring Safety:** Proper sizing minimizes risks of leaks, over-pressurization, or pipe failure.
- Compliance with Standards:** Adhering to industry codes and standards requires accurate pipe sizing to meet safety and regulatory requirements.

Basic Principles of Nitrogen Gas Pipe Sizing

Before diving into the specifics of a nitrogen gas pipe sizing chart, it's essential to understand some core principles:

- Flow Rate and Volume:** Flow rate, typically measured in cubic feet per minute (CFM) or liters per minute (L/min), determines the necessary pipe size. Accurate flow calculations consider the maximum expected flow to avoid undersizing.
- Pressure Loss and Friction:** As nitrogen flows through pipes, friction causes pressure loss. Larger pipes reduce friction and pressure drops, but they may be more costly. Conversely, smaller pipes increase friction and pressure loss.
- Velocity Limits:** Maintaining appropriate velocity (usually between 20-40 ft/sec for gases) prevents noise, vibration, and excessive wear on piping components.
- Material Compatibility:** Materials used for nitrogen piping must be compatible with inert gases and resist corrosion, influencing pipe selection and sizing.

How to Use a Nitrogen Gas Pipe Sizing Chart

A typical nitrogen gas pipe sizing chart provides a visual guide to select pipe diameters based on flow rates and pressure conditions. Here's how to interpret and apply it:

Step 1: Determine Your System Parameters

- Identify the key parameters: Required flow rate (CFM or L/min) Operating pressure (PSI)

or bar) Pipe length Allowable pressure drop

Step 2: Locate Flow Rate on the Chart Find the row or column representing your flow rate. The chart usually groups flow rates into ranges for ease of use.

Step 3: Match with Pressure and Velocity Constraints Select the pipe diameter that provides the required flow rate without exceeding recommended velocity limits and maintaining acceptable pressure drops.

Step 4: Confirm Material and Installation Factors Ensure the selected pipe size is compatible with the material, installation environment, and safety standards.

Common Pipe Sizes and Their Applications Nitrogen systems typically utilize standard pipe sizes, which may include:

- 1/4 inch (6.35 mm)
- 3/8 inch (9.52 mm)
- 1/2 inch (12.7 mm)
- 3/4 inch (19.05 mm)
- 1 inch (25.4 mm)
- 1 1/2 inch (38.1 mm)
- 2 inch (50.8 mm)
- 3 inch (76.2 mm)

The choice depends on flow requirements, pressure, and system layout.

Factors Influencing Pipe Sizing for Nitrogen Gas Several factors must be considered to select the correct pipe size:

- Flow Rate Requirements:** Higher flow rates necessitate larger pipes to prevent excessive velocity and pressure drops.
- Pressure Loss Limits:** Designs often specify maximum allowable pressure drops (e.g., 2% of system pressure), influencing pipe diameter choices.
- Pipe Length:** Longer runs increase pressure loss, often requiring larger diameters or additional pressure compensation.
- System Operating Pressure:** Higher pressure systems may tolerate smaller diameters, but safety margins must be maintained.
- Environmental Conditions:** Corrosive environments or extreme temperatures impact material choice and size considerations.

Standard Calculations for Pipe Sizing While charts provide quick reference, understanding the underlying calculations enhances accuracy:

Continuity Equation $Q = A \times v$ Where: Q = flow rate A = cross-sectional area of pipe v = velocity of gas

Rearranged for diameter: $A = \frac{Q}{v}$ and $D = 2 \times \sqrt{\frac{A}{\pi}}$

Darcy-Weisbach Equation for Pressure Loss $\Delta P = f \times \frac{L}{D} \times \frac{\rho \times v^2}{2}$ Where: ΔP = pressure drop f = friction factor L = length of pipe D = diameter ρ = density of nitrogen v = velocity

Using these equations, engineers can verify the suitability of a chosen pipe size based on flow and pressure requirements.

Industry Standards and Guidelines Various standards guide nitrogen pipe sizing:

- ASME B31.3 Process Piping Code:** Provides design and safety criteria.
- ISO 8573-1:** Specifies compressed air quality, including inert gases.
- ANSI/ASME B36.10 and B36.19:** Pipe dimensions and specifications.

Adhering to these standards ensures system safety, reliability, and compliance.

Common Mistakes to Avoid in Nitrogen Pipe Sizing

- Undersizing Pipes:** Leading to high velocity, noise, and pressure drops.
- Overlooking Pressure Drop Limits:** Causing inefficient operation or system failure.
- Ignoring Material Compatibility:** Resulting in corrosion or contamination.
- Neglecting Future Expansion:** Limiting system flexibility and increasing costs later.

Conclusion A nitrogen gas pipe sizing chart is a vital component in designing efficient, safe, and cost-effective nitrogen systems. By understanding the principles behind pipe sizing, accurately calculating flow and pressure parameters, and following industry standards, engineers and technicians can select the appropriate pipe diameters for their specific applications. Always consider operational conditions, material compatibility, and safety margins when making sizing decisions. Properly sized piping not only optimizes system performance but also prolongs equipment lifespan and ensures regulatory compliance. Whether for small laboratory setups or large industrial plants, mastering the use of a nitrogen gas pipe sizing chart is fundamental to successful system design and operation. Regular consultation of updated charts and standards, combined with sound engineering judgment, will lead

to optimal results in nitrogen gas piping projects.

Nitrogen Gas Pipe Sizing Chart: An In-Depth Analysis for Industrial Applications

In the realm of industrial processing, manufacturing, and laboratory operations, the reliable delivery of nitrogen gas is essential for maintaining safety, efficiency, and product quality. Central to this reliability is the proper sizing of nitrogen gas piping systems, which directly influences flow capacity, pressure maintenance, and operational safety. This comprehensive review aims to elucidate the critical aspects of nitrogen gas pipe sizing chart, providing engineers, technicians, and industry professionals with a thorough understanding of the principles, considerations, and best practices involved.

Understanding the Importance of Proper Pipe Sizing for Nitrogen Gas Systems

Nitrogen, a colorless, inert gas, is widely used across various industries including pharmaceuticals, food processing, electronics manufacturing, and oil & gas operations. When transporting nitrogen from supply sources to point-of-use applications, the integrity of the piping system ensures consistent flow and pressure, preventing issues such as flow restrictions, pressure drops, or system failures. Incorrectly sized piping can lead to numerous operational problems:

- Flow Restrictions:** Undersized pipes increase resistance, reducing flow rate and efficiency.
- Pressure Drop:** Excessive pressure loss leads to inadequate nitrogen delivery at the point of use.
- Increased Energy Consumption:** Overcome pressure drops with higher compressor output, increasing operational costs.
- Safety Hazards:** Poorly designed systems risk leaks or ruptures, especially under high-pressure conditions.
- Operational Downtime:** System failures or inefficiencies can result in costly shutdowns.

Therefore, an accurate nitrogen gas pipe sizing chart serves as an essential tool for designing and maintaining safe, efficient piping systems.

Fundamental Principles of Pipe Sizing for Nitrogen Gas

Proper pipe sizing involves understanding the interplay of several physical and operational parameters:

- Flow Rate:** The volume of nitrogen required per unit time (e.g., SCFM or Nm³/h).
- Pressure Requirements:** The pressure at the source and the downstream application.
- Pipe Material and Diameter:** Influences flow capacity and pressure drops.
- Velocity Limits:** Ensuring velocities remain within acceptable ranges to prevent erosion, noise, and pressure loss.
- System Length and Configuration:** Longer runs or complex layouts increase pressure drops.

The primary goal is to select a pipe diameter that balances these factors, ensuring sufficient flow while minimizing pressure loss and maintaining safety.

The Role of Pipe Sizing Charts in System Design

A nitrogen gas pipe sizing chart provides a visual or tabular guide to determine appropriate pipe diameters based on flow rates, pressure, and velocity constraints. These charts typically incorporate industry standards, empirical data, and calculations based on fluid dynamics principles. Key benefits include:

- Simplified Selection Process:** Provides quick reference points for engineers.
- Ensures Compliance:** Aligns with industry standards such as ASME B31.3 or ISO piping codes.
- Improves Safety and Efficiency:** Promotes optimal pipe diameters that prevent issues related to undersizing or oversizing.
- Facilitates Cost-Effective Design:** Avoids unnecessary material costs or energy consumption.

Components of a Nitrogen Gas Pipe Sizing Chart

A comprehensive nitrogen gas pipe sizing chart typically includes:

- Flow Rate Ranges:** Indicating the volume of nitrogen in SCFM

(Standard Cubic Feet per Minute) or Nm³/h. Pipe Diameters: Usually in inches or millimeters, representing the available standard sizes. Recommended Velocity Ranges: To prevent erosion and noise, often maintained between 20-40 ft/sec (6-12 m/sec). Pressure Drop Data: Expressed as psi/ft or kPa/m, indicating acceptable pressure loss. Material Considerations: Chart may specify ratings based on pipe material (e.g., carbon steel, stainless steel, copper). System Length Factors: Adjustments for longer runs, considering cumulative pressure drops. Design Considerations and Calculations

Creating or interpreting a nitrogen gas pipe sizing chart involves understanding key calculations:

- 1. Volumetric Flow Rate Conversion** Flow rates are often specified at standard conditions. Conversion considerations include temperature, pressure, and gas compressibility.
- 2. Velocity Constraints** Maintaining flow velocity within recommended limits prevents noise, vibration, and erosion. For nitrogen, typical maximum velocities are: 20-40 ft/sec (6-12 m/sec). Designers use this to determine the minimum pipe diameter for a given flow.
- 3. Darcy-Weisbach Equation** Used to estimate pressure drop:

$$\Delta P = f \times \frac{L}{D} \times \frac{\rho V^2}{2}$$
 Where:
 - ΔP = pressure loss
 - f = Darcy friction factor
 - L = length of pipe
 - D = diameter
 - ρ = density of nitrogen
 - V = flow velocity
 By rearranging and referencing empirical data, engineers select piping diameters that keep pressure drops within acceptable limits.
- 4. Standard Pipe Sizes and Availability** Practical considerations include selecting from standard pipe sizes, which may influence the final choice based on availability and cost.

Interpreting and Utilizing a Nitrogen Gas Pipe Sizing Chart

To effectively use a nitrogen gas pipe sizing chart, follow these steps:

- Determine Required Flow Rate:** Establish the maximum flow needed at the system's point of use.
- Identify System Parameters:** Note the supply pressure, desired delivery pressure, and system length.
- Consult the Chart:** Find the flow rate range on the chart, then select the pipe diameter that corresponds to the acceptable velocity range.
- Account for System Length:** Make adjustments for pressure drop over longer distances, potentially selecting a larger diameter.
- Verify Material Compatibility:** Ensure material strength and corrosion resistance suit operational conditions.
- Perform Calculations:** Cross-check with detailed calculations if necessary, especially for critical applications.

Common Industry Standards and Guidelines

Several standards inform the creation and application of nitrogen gas pipe sizing charts:

- ASME B31.3 Process Piping:** Provides design criteria for process piping, including flow velocities and pressure drops.
- ISO 5167:** Covers measurement and flow calculations.
- NFPA 55:** Addresses compressed gases storage, handling, and piping.

Manufacturer Data: Many pipe producers supply detailed flow charts based on empirical data. Adherence to these standards ensures safety, efficiency, and regulatory compliance.

Challenges and Limitations

While pipe sizing charts are invaluable, they are not without limitations:

- Flow Variability:** Fluctuating demand can complicate sizing.
- Complex System Layouts:** Multiple branches, valves, or expansions require detailed analysis beyond simple charts.
- Material and Corrosion Factors:** Material degradation over time may affect flow capacity.
- Temperature Effects:** Changes in temperature influence gas density and pressure, impacting flow calculations.
- Operational Safety Margins:** Overly conservative sizing can increase costs; under-sizing risks safety.

Therefore, a combination of chart consultation, detailed calculations, and professional judgment is essential.

Best Practices for Effective Nitrogen Pipe Sizing

- Perform Detailed System Analysis:** Consider all operational parameters.
- Use Accurate Data:** Obtain precise flow and pressure requirements.
- Consult Multiple Sources:** Cross-reference

charts, standards, and manufacturer data. Plan for Future Expansion: Design with scalability in mind. Regularly Maintain and Inspect: Monitor for corrosion, leaks, and pressure drops. Engage Experienced Engineers: Ensure proper interpretation and application of sizing data. Conclusion The nitrogen gas pipe sizing chart is an essential tool that simplifies the complex process of designing safe, efficient, and cost-effective nitrogen piping systems. By understanding the underlying principles such as flow dynamics, pressure considerations, and material constraints, industry professionals can make informed decisions that optimize system performance while maintaining compliance with safety standards. As industries continue to evolve, so too will the sophistication of sizing charts and related calculations. Continuous learning, adherence to standards, and leveraging technological advancements will ensure that nitrogen gas systems remain reliable and safe across diverse applications. Properly sized piping not only ensures operational excellence but also safeguards personnel and assets, reaffirming the critical importance of meticulous planning and diligent application of nitrogen gas pipe sizing charts in industrial system design.

Question Answer

What is a nitrogen gas pipe sizing chart and why is it important?

A nitrogen gas pipe sizing chart is a reference tool used to determine the appropriate pipe diameter for nitrogen gas systems based on flow rate and pressure requirements. It ensures safe, efficient, and cost-effective installation by preventing pressure drops and system failures.

How do I use a nitrogen gas pipe sizing chart to select the right pipe diameter?

You input your system's flow rate and pressure requirements into the chart, which then indicates the suitable pipe size to maintain optimal flow and pressure without excessive pressure loss or turbulence.

What factors influence nitrogen pipe sizing decisions?

Factors include flow rate, pressure drop allowances, pipe length, pipe material, operating pressure, and system safety standards. These determine the appropriate pipe diameter for efficient nitrogen delivery.

Can a nitrogen gas pipe sizing chart be used for different pipe materials?

While the chart provides general guidance, pipe material affects flow characteristics and pressure loss. Always consult specific charts or guidelines for materials like stainless steel, copper, or plastics for more accurate sizing.

What are common pipe sizes used in nitrogen gas systems?

Common sizes range from small diameters like ¼ inch for precision applications to larger diameters such as 2 inches or more for high-volume or industrial systems, depending on flow requirements.

How does pipe length affect nitrogen gas pipe sizing?

Longer pipe runs increase pressure drop, often requiring larger pipe diameters to compensate and maintain consistent flow and pressure throughout the system.

Are there standard guidelines or codes for nitrogen pipe sizing?

Yes, standards such as ASME B31.3, ISO, and industry-specific codes provide guidelines for piping design, including sizing, to ensure safety and compliance.

What are the consequences of undersizing or oversizing nitrogen pipes?

Undersized pipes can cause excessive pressure drops, reduced flow, and system inefficiency, while oversized pipes are costlier and may lead to unnecessary material use without performance benefits.

Is it necessary to consult a professional when using a nitrogen gas pipe sizing chart?

Yes, consulting a qualified engineer or piping specialist ensures accurate sizing considering all system variables, safety standards, and industry regulations.

Where can I find reliable nitrogen gas pipe sizing charts?

Reliable charts can be found through industry suppliers, engineering handbooks, standards organizations like ASME, or specialized piping software tools designed for gas system design.

Related keywords: nitrogen piping specifications, gas pipe sizing calculator, nitrogen flow rate chart, pneumatic piping dimensions, nitrogen pipeline design, gas flow engineering, compressed gas pipe sizing, industrial nitrogen piping, nitrogen distribution system, pipe diameter chart